

Advanced Walk-Back function

The advanced walk-back function allows direct input of coordinates in the vLoc3 RTK-Pro receiver.

Requirements:

- I. This function requires that you have enabled the "Walk-Back" function in the MyLocator3 desktop application. If "Walk-Back" is displayed in the main menu of the receiver (open by long pressing the "i" key), the function is already enabled. If this is not the case, please contact us.
- II. In addition, you should know the "Quick Guide Walk-Back".

Application:

For the direct input of coordinates, only the vLoc3 RTK-Pro receiver is required. Access to the VMMap Cloud is not necessary.

1. Switch on the vLoc3 RTK-Pro receiver
2. Open the user menu with a long press on the "i" key
3. Scroll with the "+" or "-" button to the item "Walk-Back" and press the "Enter" button to open the submenu
4. Select the item "Manual Entry" with the "Enter" key
5. Key functions:
 - a. With a short press of the power button, the current location is entered as longitude and latitude when GPS is received. This makes the entry easier if you are already close to the point you are looking for.
 - b. With the "+" or "-" key, the first number can now be entered.
 - c. To enter the next number, briefly press the "f" key.
 - d. This will continue until the desired latitude and longitude are entered.
 - e. To save the point, press the "Enter" key.
6. Now the RTK receiver will navigate you back to the desired point using the arrow, or crosshair. (See "vLoc3 RTK-Pro Quick Start Guide Walk Back").